

9-3. FUNCTION OF DIP SWITCH

Switch	Pole	Function	Operation by switch		Effective timing	Remarks																																																										
			ON	OFF																																																												
SW1 Function setting	1	Thermistor <Room temperature detection> position	Built-in remote controller	Indoor unit	Under suspension	<div style="border: 1px solid black; padding: 2px;">Address board</div> <Initial setting> ON <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>10</td></tr></table> OFF <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>10</td></tr></table>	1	2	3	4	5	6	7	8	9	10	1	2	3	4	5	6	7	8	9	10																																						
	1	2	3	4			5	6	7	8	9	10																																																				
	1	2	3	4			5	6	7	8	9	10																																																				
	2	Filter clogging detection	Provided	Not provided																																																												
	3	Filter cleaning sign	2,500h	100h																																																												
	4	Fresh air intake	Effective	Not effective																																																												
	5	Switching remote controller display	Thermo ON signal display	Indicating fan operation ON/OFF																																																												
	6	Humidifier control	Fan operation at Heating mode	Thermo ON operation at Heating mode																																																												
	7	Air flow at	Low *	Extra low *																																																												
	8	Heat thermo OFF	Setting air flow	Depends on SW1-7																																																												
9	Auto restart function	Effective	Not effective																																																													
10	Power ON/OFF by breaker	Effective	Not effective																																																													
SW2 Capacity code setting	1~6	<table border="1" style="width: 100%; text-align: center;"> <tr> <th>MODELS</th> <th>SW 2</th> <th>MODELS</th> <th>SW 2</th> </tr> <tr> <td>PMFY-P06NBMU-E</td> <td>ON <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table> OFF <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table></td> <td>PMFY-P12NBMU-E</td> <td>ON <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table> OFF <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table></td> </tr> <tr> <td>PMFY-P08NBMU-E</td> <td>ON <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table> OFF <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table></td> <td>PMFY-P15NBMU-E</td> <td>ON <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table> OFF <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table></td> </tr> </table>	MODELS	SW 2	MODELS	SW 2	PMFY-P06NBMU-E	ON <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table> OFF <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table>	1	2	3	4	5	6	1	2	3	4	5	6	PMFY-P12NBMU-E	ON <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table> OFF <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table>	1	2	3	4	5	6	1	2	3	4	5	6	PMFY-P08NBMU-E	ON <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table> OFF <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table>	1	2	3	4	5	6	1	2	3	4	5	6	PMFY-P15NBMU-E	ON <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table> OFF <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table>	1	2	3	4	5	6	1	2	3	4	5	6	Before power supply ON	<div style="border: 1px solid black; padding: 2px;">Indoor controller board</div> <Initial setting> Set for each capacity.
		MODELS	SW 2	MODELS	SW 2																																																											
		PMFY-P06NBMU-E	ON <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table> OFF <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table>	1	2	3	4	5	6	1	2	3	4	5	6	PMFY-P12NBMU-E	ON <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table> OFF <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table>	1	2	3	4	5	6	1	2	3	4	5	6																																			
		1	2	3	4	5	6																																																									
1	2	3	4	5	6																																																											
1	2	3	4	5	6																																																											
1	2	3	4	5	6																																																											
PMFY-P08NBMU-E	ON <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table> OFF <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table>	1	2	3	4	5	6	1	2	3	4	5	6	PMFY-P15NBMU-E	ON <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table> OFF <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table>	1	2	3	4	5	6	1	2	3	4	5	6																																					
1	2	3	4	5	6																																																											
1	2	3	4	5	6																																																											
1	2	3	4	5	6																																																											
1	2	3	4	5	6																																																											
1	Heat pump/Cool only	Cooling only	Heat pump																																																													
2	Louver	Available	Not available																																																													
3	Vane	Available	Not available																																																													
SW3 Function setting	1~10	4	Vane swing function	Available	Not available	Under suspension	<div style="border: 1px solid black; padding: 2px;">Indoor controller board</div> <Initial setting> ON <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>10</td></tr></table> OFF <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>10</td></tr></table>	1	2	3	4	5	6	7	8	9	10	1	2	3	4	5	6	7	8	9	10																																					
		1	2	3	4			5	6	7	8	9	10																																																			
		1	2	3	4			5	6	7	8	9	10																																																			
		5	Vane horizontal angle	Second setting *6	First setting																																																											
		6	Vane cooling limit angle setting *4	Horizontal angle	Down B, C																																																											
		7	Changing the opening of linear expansion valve when the thermostat is OFF	Effective	Not effective																																																											
		8	Heating 4deg. up	Not effective	Effective																																																											
		9	Target superheat setting *5	—	—																																																											
		10	Target sub cool setting *5	—	—																																																											
		(*4) At cooling mode, each angle can be used only 1 hour. (*5) SW 3-9 setting PMFY-P06, P08NBMU-E=ON PMFY-P12, P15NBMU-E=OFF SW 3-10 setting PMFY-P06, P08NBMU-E=ON PMFY-P12, P15NBMU-E=OFF Do not use SW3-9, 10 as trouble might be caused by the usage condition. *6 Second setting means first setting.																																																														
SW4 Model Selection (Setting for PMFY series)	1~5	In case replacing the indoor controller board, make sure to set the switch to the initial setting, which is shown below.			Before power supply ON	<div style="border: 1px solid black; padding: 2px;">Indoor controller board</div>																																																										
		PMFY-P-NBMU-E ON <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr></table> OFF <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr></table>	1	2			3	4	5	1	2	3	4	5	PMFY-P-NBMU-E ₁ ON <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr></table> OFF <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr></table>	1	2	3	4	5	1	2	3	4	5	PMFY-P-NBMU-E#2/ER3/ER4/ER5 ON <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr></table> OFF <table border="1" style="display: inline-table;"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr></table>	1	2	3	4	5	1	2	3	4	5																												
1	2	3	4	5																																																												
1	2	3	4	5																																																												
1	2	3	4	5																																																												
1	2	3	4	5																																																												
1	2	3	4	5																																																												
1	2	3	4	5																																																												